

# LOAN DOCUMENT

PHOTOGRAPH THIS SHEET

DTIC ACCESSION NUMBER

LEVEL

INVENTORY

## DOCUMENT IDENTIFICATION

H  
A  
N  
D  
L  
E  
  
W  
I  
T  
H  
  
C  
A  
R  
E

## DISTRIBUTION STATEMENT

ACCESSION STATE	
NTIS	GRAB
DTIC	TRAC
UNANNOUNCED	
JUSTIFICATION	
BY	
DISTRIBUTION/	
AVAILABILITY CODES	
DISTRIBUTION	AVAILABILITY AND/OR SPECIAL
A-1	

DISTRIBUTION STAMP

DATE ACCESSIONED

DATE RETURNED

19981223 021

DATE RECEIVED IN DTIC

REGISTERED OR CERTIFIED NUMBER

PHOTOGRAPH THIS SHEET AND RETURN TO DTIC-FDAC

*10C  
12-8-78*

**UNCLASSIFIED**

NO DISTRIBUTION  
STATEMENT


**NADC**  
**Tech. Info.**

APPENDIX 35  
TEST PROCEDURE FOR SYSTEM CONTROLLER  
FINAL SOFTWARE REPORT  
DATA ITEM NO. A005

**INTEGRATED ELECTRONIC WARFARE SYSTEM  
ADVANCED DEVELOPMENT MODEL (ADM)**

*1800987-35*

PREPARED FOR:  
NAVAL AIR DEVELOPMENT CENTER  
WARMINSTER, PENNSYLVANIA  
CONTRACT N62269-75-C-0070



APPENDIX 35  
TEST PROCEDURE FOR SYSTEM CONTROLLER  
FINAL SOFTWARE REPORT  
DATA ITEM A005

INTEGRATED ELECTRONIC WARFARE SYSTEM (IEWS)  
ADVANCED DEVELOPMENT MODEL (ADM)

Contract No. N62269-75-C-0070


Prepared for:

Naval Air Development Center  
Warminster, Pennsylvania

Prepared by:

RAYTHEON COMPANY  
Electromagnetic Systems Division  
6380 Hollister Avenue  
Goleta, California 93017

1 OCTOBER 1977



RAYTHEON COMPANY  
LEXINGTON, MASS. 02173

CODE IDENT N

53959-GT-0301

SHEET 1 OF 2

B

TYPE OF SPEC

## Software Test Specification

TITLE OF SPEC

## Test Procedure for System Controller, IEDS.

FUNCTION	APPROVED	DATE	FUNCTION	APPROVED	DATE
WRITER	D.B. Eldridge	9/21/76			

## REVISIONS

CHK	DESCRIPTION	REV	CHK	DESCRIPTION	REV

21 September 1976

PREPRODUCTION TEST PROCEDURE

PART I

PERFORMANCE TEST UNDER LABORATORY CONDITIONS

FOR

SYSTEM CONTROLLER, IEWS

CONTRACT-N62269-74-C-0070

MANUFACTURER--RAYTHEON COMPANY

Total Pages in the Procedure: 27

TABLE OF TESTS

<u>TEST</u>	<u>NAME</u>	<u>PAGE</u>
2.1	Operator Control Test	I-5
2.1.1	Front Panel Reset	I-5
2.1.2	Local Control Panel	I-5
2.2	Master Bus Module Tests	I-8
2.2.1	Master Processor Self-Test	I-8
2.2.2	Master Bus Memory Test	I-9
2.2.3	Master Bus PIN/RTC Module Test	I-10
2.2.4	Master Bus DSI $\emptyset$ Module Test	I-11
2.2.5	Master Bus SCM Test	I-12
2.2.6	Master Bus LD/LR Module Test	I-13
2.3	Slave Bus 1 Module Test	I-14
2.3.1	Slave Processor 1 Self-Test	I-14
2.3.2	Slave Bus 1 Memory Test	I-15
2.3.3	Slave Bus 1 PIN/RTC Module Test	I-16
2.3.4	Slave Bus 1 DSI $\emptyset$ Module Test	I-16
2.4	Slave Bus 2 Module Tests	I-18
2.4.1	Slave Processor 2 Self-Test	I-18
2.4.2	Slave Bus 2 Memory Test	I-19
2.5	Bus Tests	I-20
2.5.1	Master Bus Test	I-20
2.5.2	Slave Bus 1 Test	I-20
2.5.3	Slave Bus 2 Test	I-21
2.6	System Test	I-22

LIST OF TEST EQUIPMENT

1. Local Control Panel (854952-1) and Control Panel Interface Module (894629-4)
2. 4K PROM/RAM Module (950026-4)
3. Signal Sorter (893651)
4. Auxiliary Bus Monitor
5. Simulated System Controller or Software Development Center
6. Test Function Unit (see Appendix A)

Cables (see Appendix A)

- a. Signal Sorter Bus Cable
- b. Auxiliary Bus Cable
- c. Daisy Chain Bus Cables (2)
- d. Serial I/O Bus Cable
- e. Power Cable

See Appendix A for basic test equipment configuration.

A number of programs are required to facilitate system testing. Some are contained as firmware in the 4K PROM/RAM module. Others are software programs which must be loaded into a two-port 4K RAM memory in the Simulated System Controller or Software Development Center as called out in the test procedure. A list of test programs and associated document control numbers are contained in Appendix B.

Tests in some sections require the use of a MOVE utility program, located on the 4K PROM/RAM, to relocate programs from 4K memory sectors on the Master Bus to 4K sectors on the Slave Buses. A description of the use of this program is contained in Appendix C.

Some tests require the operator to use the SSC or SDC to load external software into the 4K SSC or SDC memory accessible to the SC. A description of this load procedure is contained in Appendix D. Use of the MOVE utility program contained in the 4K PROM/RAM is also required.

LIST OF ABBREVIATIONS

AUX BUS	AUXILIARY BUS
CPI	CONTROL PANEL INTERFACE MODULE
DSIØ	DUAL CHANNEL SERIAL IØ MODULE
LCP	LOCAL CONTROL PANEL
LD/LR	LINE DRIVER/LINE RECEIVER MODULE
PIN/RTC	PRIORITY INTERRUPT NETWORK/REAL TIME CLOCK MODULE
SC	SYSTEM CONTROLLER
SCM	SYSTEM CONTROL MODULE
SDC	SOFTWARE DEVELOPMENT CENTER
SIØ	SERIAL IØ CHANNEL
SS	SIGNAL SORTER
SSC	SIMULATED SYSTEM CONTROLLER
TFU	TEST FUNCTION UNIT

## TEST PROCEDURES

1. GENERAL - Unless specified otherwise, all tests shall be performed under the following conditions:
  - (a) Atmospheric Conditions - The tests shall be performed at prevailing open environment atmospheric conditions.
  - (b) Input Power - The input power shall be 115 volt, 400 Hertz, three phase.
  - (c) Configuration - Unless otherwise specified, all tests shall be performed using the basic test configuration of Appendix A, with power applied to all units.
  - (d) Equipment Operation - The test operator shall have familiarity with the operation of both the test equipment and the unit under test.
2. UNIT TEST - Apply power to the basic configuration and momentarily depress the RESET pushbutton on the SC front panel

### 2.1 OPERATOR CONTROL

#### 2.1.1 Front Panel Reset

- (a) Requirement - Front Panel Reset shall initialize SC, SS and externally cabled SIØ and Daisy Chain devices.
- (b) Conditions - Basic test configuration.
- (c) Measurement - Depress Front Panel RESET pushbutton. Test Function Unit lights SIØCLR and DCMCL should be on. RUN light on LCP should be off.

#### 2.1.2 Local Control Panel

Initial

- (a) Requirement - LCP functions shall be fully operational.
- (b) Conditions - Basic test configuration.
- (c) Measurement -
  - i. Exercise LCLR function. Test Function unit lights SIØCLR and DCMCL should be on when LCP EXECUTE pushbutton is depressed.

Witnessed by:

Initial

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

ii. Exercise PCLR function as in (i).  
Lights should remain off.

Initial

iii. Exercise REGSEL function. Load the following hexadecimal patterns into the data registers and verify upon load completion that the contents of each register is unchanged.

SR 5555

PR 3333

BR 0F0F

XR 0OFF

ACR AAAA

ER CCCC

WR F0F0

AR FF00

Initial

Load the following patterns into each data register (SR, PR, BR, XR, ACR, ER, WR, AR).

0000

FFFF

5555

AAAA

Initial

iv. Exercise the Memory function. Store and Fetch the following data patterns to memory location 0000:

0000

FFFF

5555

AAAA

Verify the data returned is the same as data entered.

Witnessed by:

Customer Representative \_\_\_\_\_

Initial

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

Store i the following set of data patterns to memory, starting at memory location 0000:

0000  
0001  
0002  
0003  
0004  
0005  
0006  
0007

Fetch i the entered data starting from memory location 0000. Verify that data returned from memory is the same as data entered to memory.

v. Initial  
Exercise the STEP/HALT and RUN functions. Use the LCP to enter the following simple Load programs into memory, starting at location 0000.

<u>Address</u>	<u>Contents</u>	<u>Program</u>
0000	108C	LDS A P*
0001	5555	DC '5555
0002	86FD	JMP-2

Initialize register PR to 0000 and register ACR to AAAA, using the LCP, and depress the RESET button. Perform the STEP/HALT function such that one instruction execution is performed (two pushbutton depressions). Verify that the PR register contains 0002, the ACR register contains 5555, and that the AR register contains FFFD. Perform the RUN function. Perform the HALT function. Observe that the LCP Run light is off. Verify that the PR and AR registers contain one of the following two sets of data:

PR                    AR  
0000                    FF4C

or

0002                    FFFD

Initial

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

Enter the following simple Store program into memory, starting at location 0000.

Address	Contents	Program
0000	008C	STS A P*
0001	5555	DC '5555
0002	86FD	JMP-2

Initialize register PR to 0000 and register ACR to AAAA, and depress the RESET button. Perform the STEP/HALT function such that one instruction execution is performed (two pushbutton depressions). Verify that the PR register contains 0002 and that memory location 0001 contains AAAA.

## 2.2 MASTER BUS MODULE TESTS

Initial

### 2.2.1 Master Processor Self-Test

(a) Requirements - Test all Master Processor microinstructions and microprogram branches that implement the processor instruction set and depend only on program execution from a zero-originated 4K memory. Additionally list instruction functions using a pseudo-random sample of data word values.

(b) Conditions - Basic test configuration.

(c) Measurement - Enter 0080 into memory locations 0080 and 0081. Initialize register PR to 0100 and depress the RESET button. Perform the RUN function. The LCP RUN light shall come on for a period of approximately 15 seconds. After the RUN light has gone off, examine memory locations 0080 and 0081 and verify that they contain the following information.

Memory Location	Contents	Meaning
0080	0000	Halt Code
0081	0000	Success Code

Witnessed by:

Initial

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

## 2.2.2 Master Bus Memory Test

(a) Requirements - Test Master Bus memory via pattern and address tests.

(b) Conditions - Basic test configuration

(c) Measurement - Enter the starting address of the memory sector to be tested into memory location 0080 and the ending address of the sector into location 0081. Initialize register PR to 0600 and depress the RESET button. Perform the RUN function. The LCP RUN light will come on for a period proportional to the size of the tested memory sector (~7 sec. for each 4K block). After the RUN light has gone off, examine memory locations 0080 and 0081 and verify that they contain the following information.

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
0080	0000	Halt Code
0081	0000	Success Code

Initial

Execute the Master Bus memory test for the following memory sectors:

From Starting Address to Ending Address

2000	6FFF
8000	9FFF
C000	CFFF

Initial

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

### 2.2.3 Master Bus PIN/RTC Module Test

(a) Requirements - Test the Master Bus Processor's ability with respect to the PIN/RTC to:

- (i) Read and write various data patterns to the Mask Register.
- (ii) Read RTC counter and verify that it is cleared.
- (iii) Read Interrupt Status Register and verify that it is cleared.

(b) Conditions - Basic test configuration

(c) Measurement - Load the PIN/RTC test program into the SSC or SDC. Transfer the contents of the 4K memory, origin C000, to the 4K memory, origin 2000 using the MOVE routine. Enter 0080 into memory locations 0080 and 0081. Initialize register PR to 2000 and depress the RESET button. Place the DC/INRUPTS switch on the TFU into the DC position. Perform the RUN function, which will cause the processor to run for a fraction of a second. Examine memory locations 0080 and 0081 and verify that they contain the following information:

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
0080	0000	Halt Code
0081	0000	Success Code

Initial

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

#### 2.2.4 Master Bus DSIG Module Test

(a) Requirements - Test the Master Bus Processor's ability with respect to the DSIG to:

- (i) Read the Status Word and verify that it is cleared.
- (ii) Read Mask bits and verify that they are cleared.
- (iii) Write and Read Mask bits.
- (iv) Transmit and receive serial data and check status information for various control word patterns.

(b) Conditions - Basic test configuration, except that the procedure is to be repeated four times, with the SIØ bus cable (SC plug end) connected to a different SC connector jack for each test pass. These are:

<u>Test Pass</u>	<u>SC Jack Connection</u>
1	J1
2	J2
3	J3
4	J4

(c) Measurement - Load the DSIG test program into the SSC or SDC. Transfer the contents of the 4K memory, origin C000, to the 4K memory, origin 2000, using the MOVE routine. For each pass, enter the address of the SIØ channel to be tested in memory locations 0080 and 0081. Initialize register PR to 2002 and depress the RESET button. Perform the RUN function, which will cause the processor to run for 5 seconds. Examine memory locations 0080 and 0081 and verify that they contain the following information:

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
0080	0000	Halt Code
0081	0000	Success Code

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

## 2.2.4 Master Bus DSIG Module Test (Continued)

### (c) Measurement (Continued)

Also verify at the completion of each pass that the RCV BUFFER FULL light on the Test Function Unit is on. Depress the front panel RESET pushbutton and verify that the SIG CLR light comes on and the RCV BUFFER FULL light goes off at the Test Function Unit.

SIG channel addresses for each pass are as follows:

<u>Test Pass</u>	<u>Channel Address</u>
1	FC00
2	FC04
3	FC08
4	FC0C

## 2.2.5 Master Bus SCM Test

Initial

### (a) Requirements -

- (i) Read Breakpoint Status and verify that it is cleared.
- (ii) Read Watchdog Timer Status and verify that it is cleared.
- (iii) Test Breakpoint Register for Breakpoint Halt operation.
- (iv) Test ROM and auto-start features.
- (v) Test Watchdog Timer.
- (vi) Test Master Bus Clear distribution.

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

### 2.2.5 Master Bus SCM Test (Continued)

(b) Conditions - Basic test configuration. (but without SCM bootstrap PROMS)

(c) Measurement - Load the SCM test into the SSC or SDC. Transfer the contents of the 4K memory, origin C000, to the 4K memory, origin 2000, using the MOVE routine. Enter 0080 into memory locations 0080 and 0081. Initialize Register PR to 2004 and depress the RESET button. Perform the RUN function, which will cause the processor to run for several seconds.

Depress the RELOAD button on the TFU. Examine memory locations 0080 and 0081 and verify that they contain the following information:

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
0080	0000	Halt Code
0081	0000	Success Code

Initial

### 2.2.6 Master Bus LD/LR Test

(a) Requirements -

(i) Verify the POWERFAIL function.

(ii) Verify the SKIP function.

(b) Condition - Basic test configuration.

(c) Measurement - Remove power from the SC\*. Verify that the POWERFAIL light on the TFU is on. Apply power to the SC. Verify that the SCPWR FAIL light is off. Depress and release the front panel RESET pushbutton.

Using the LCP, enter the following simple program into memory.

<u>Location</u>	<u>Contents</u>	<u>Code</u>
C000	104C	LDS A(P*)
C001	0000	0000
C002	86FD	JMP-2
C003	B800	HALT

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

\*CAUTION: This test may alter the contents of the 4K RAM located in the SSC or SDC due to power down/up transients.

Initialize register PR to C000 and depress the RESET button. Perform the RUN function, putting the processor in the program loop. Depress the DC SKIP pushbutton on the TFU. Verify that the processor halts with the PR register equal to C004.

Initial

### 2.3 SLAVE BUS 1 MODULE TESTS

#### 2.3.1 Slave Processor 1 Self Test

(a) Requirements - Test all Slave 1 Processor microinstructions and microprogram branches that implement the processor instruction set and depend only on program execution from a zero originated 4K memory. Additionally, test instruction functions using a pseudo-random sample of data word values.

(b) Conditions - Basic test configuration.

(c) Measurement - Transfer the contents of the 4K PROM/RAM, origin 0000, to the 4K memory, origin 2000, via the MOVE utility program.

Enter 2080 into memory locations 2080 and 2081, and 0100 into memory location 2000. Depress the RESET button. Store to memory locations FFCl and FCCB in sequence with the LCP to start the Slave 1 processor. After approximately 15 seconds, examine memory location 2080 and 2081 with the LCP and verify that they contain the following information.

Memory Location	Contents	Meaning
2080	0000	Halt Code
2081	0000	Success Code

Witnessed by:

Initial

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

### 2.3.2 Slave Bus 1 Memory Test

- (a) Requirements - Test all Slave 1 Bus Memory via pattern and address tests.
- (b) Conditions - Basic test configuration
- (c) Measurement - Transfer the contents of the 4K PROM/RAM, origin 0000, to the 4K memory, origin 2000, via the MOVE utility program.

Enter the starting address of the Slave 1 memory sector to be tested into memory location 2080 and the ending address of the sector into location 2081. Enter 0600 into memory location 2000. Depress the RESET button. Store to memory locations FFCL and FFCCB in sequence with the LCP to start the Slave 1 processor. Allowing for 7 seconds of execution for each 4K of memory, examine memory locations 2080 and 2081 and verify that they contain the following information:

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
2080	0000	Halt Code
2081	0000	Success Code

Execute the Slave 1 Bus memory test for the following memory sectors.

From Starting Address to Ending Address

1000	4FFF
6000	7FFF
C000	C3FF

Initial

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

### 2.3.3 Slave Bus 1 PIN/RTC Module Test

(a) Requirements - Test the Master Bus Processor's ability with respect to the PIN/RTC to:

- (i) Read and write various data patterns to the Mask Register.
- (ii) Read RTC counter and verify that it is cleared.
- (iii) Read Interrupt Status Register and verify that it is cleared.

(b) Conditions - Basic test configuration.

(c) Measurement - Load the PIN/RTC test program into the SSC or SDC. Transfer the contents of the 4K RAM, origin C000, to the 4K memory sector origin 4000, via the MOVE utility program. Enter 2080 into memory locations 2080 and 2081, and 2000 into location 2000. Depress the RESET button. Store to memory locations FFC1 and FFCB in sequence with the LCP to start the Slave 1 processor. Examine memory locations 2080 and 2081 with the LCP and verify that they contain the following information:

2080	0000	Halt Code
2081	0000	Success Code

### 2.3.4 Slave Bus 1 DSIØ Module Test

Initial

(a) Requirements - Test the Master Bus Processor's ability with respect to the DSIØ to:

- (i) Read the Status Word and verify that it is cleared.
- (ii) Read Mask bits and verify that they are cleared.
- (iii) Write and Read Mask bits.
- (iv) Transmit and receive serial data and check status information for various control word patterns.

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

#### 2.3.4 Slave Bus 1 DSIO Module Test (Continued)

(b) Conditions - Basic test configuration, except that the procedure is to be repeated twice, with the SI $\emptyset$  bus cable (SC plug end) connected to a different SC connector jack for each test pass. These are:

<u>Test Pass</u>	<u>SC Jack Connections</u>
1	J5
2	J6

(c) Measurement - Load the DSIO Test Program into the SSC or SDC. Transfer the contents of the 4K RAM, origin C000, to the 4K memory sector origin 4000, via the MOVE utility program. For each pass, enter the SI $\emptyset$  channel address into memory locations 2080 and 2081, and 2002 into location 2000. Depress the RESET button. Store to memory locations FFCl and FFCB in sequence with the LCP to start the Slave 1 processor. After 5 seconds, examine memory locations 2080 and 2081 and verify that they contain the following information:

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
2080	0000	Halt Code
2081	0000	Success Code

Also verify, after completion of each pass, that the RCV BUFFER FULL light on the TCU is on. Depress the front panel RESET pushbutton and verify that the SI $\emptyset$ CLR light comes on and the RCV BUFFER FULL light goes off at the TCU.

SI $\emptyset$  channel addresses for each pass are as follows:

<u>Test Pass</u>	<u>Channel Address</u>
1	FC00
2	FC04

Witnessed by:

Customer Representative \_\_\_\_\_ Initial \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

## 2.4 SLAVE BUS 2 MODULE TESTS

### 2.4.1 Slave Processor 2 Self Test

(a) Requirements - Test all Slave 2 processor microinstructions and microprogram branches that implement the processor instruction set and depend only on program execution from a zero originated 4K memory. Additionally, test instruction functions using a pseudo-random sample of data word values.

(b) Conditions - Basic test configuration

(c) Measurement - Transfer the contents of the 4K PROM/RAM, origin 0000, to the 4K memory, origin 8000, via the MOVE utility program. Depress the RESET button. Enter 8080 into memory locations 8080 and 8081, and 0100 into memory location 8000. Store to memory location FFD1 and FFDB in sequence with the LCP to start the Slave 2 processor. After approximately 15 seconds, examine memory location 8080 and 8081 with the LCP and verify that they contain the following information.

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
8080	0000	Halt Code
8081	0000	Success Code

Initial

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

## 2.4.2 Slave Bus 2 Memory Test

- (a) Requirements - Test all Slave 2 Bus Memory via pattern and address tests.
- (b) Conditions - Basic test configuration
- (c) Measurement - Transfer the contents of the 4K PROM/RAM origin 0000, to the 4K memory, origin 8000, via the MOVE utility program.

Enter the starting address of the Slave 2 memory sector to be tested into memory location 8080 and the ending address of the sector into location 8081. Enter 0600 into memory location 8000. Depress the RESET button. Store to memory locations FFDB and FFDD in sequence with the LCP to start the Slave 2 processor. Allowing for 7 seconds of execution for each 4K of memory, examine memory locations 8080 and 8081 and verify that they contain the following information:

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
8080	0000	Halt Code
8081	0000	Success Code

Execute the Slave 2 bus memory test for the following memory sectors.

### From Starting Address to Ending Address

1000	1FFF
6000	7FFF
C000	C3FF

Initial

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

## 2.5 BUS TESTS

### 2.5.1 Master Bus Test

(a) Requirements - Test the following low level interrupts:  
Hung Bus Detector (1)  
Internal Interrupt Generator (1)  
SIØ (4)  
LD/LR (7)

(b) Condition - Basic test configuration

(c) Measurement - Load the Master Bus Test program into the SSC or SDC. Transfer the contents of the 4K memory, origin C000, to the 4K memory, origin 2000, using the MOVE routine. Using the LCP, enter 0080 into memory locations 0080 and 0081. Initialize register PR to 2006 and depress the RESET button. Place the DC/INRUPTS switch of the TFU in the INRUPTS position. Perform the RUN function. Verify that the RUN light on the LCP goes off and that memory contains the following information:

Memory Location	Contents	Meaning
0080	0000	Halt Code
0081	0000	Success Code

Place the DC/INRUPTS switch back into the DC position.

Initial

### 2.5.2 Slave Bus 1 Test

(a) Requirements -

(i) Test the SS connector port by controlling the SS Supervisor Processor, and by responding to MSG and POWERFAIL interrupts from the SS.

(ii) Test the following low level interrupts:  
Hung Bus Detector (1)  
SIØ (2)

(iii) Test Master Clear distribution.

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

### 2.5.2 Slave Bus 1 Test (Continued)

(b) Conditions - Basic test configuration

(c) Measurement - Load the Slave 1 Bus Test program into the SCC or SDC. Transfer the contents of the 4K memory, origin C000, to the 4K memory, origin 4000, via the MOVE utility program. Enter 2080 into memory location 2080 and 2081. Enter 200A into memory location 2000. Depress the RESET button. Store 0's to FCF1 before running slave processor 1. Store to memory location FFC1 and FFCA in sequence with the LCP to start the Slave 1 processor. Turn the SS power supply off, then on. Examine memory locations 2080 and verify that they contain the following information:

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
2080	0000	Halt Code
2081	0000	Success Code

Initial

### 2.5.3 Slave Bus 2 Test

(a) Requirements -

- (i) Write and read data patterns in each of the 16 CAM/RAM control memory locations. Verify operation of the Aux. Buffer Full Interrupt.
- (ii) Verify operation of the Aux. Hung Bus Detector interrupt function.
- (iii) Test Master Clear distribution.

(b) Condition - Basic test configuration

(c) Measurements - Load the Slave 2 Bus Test program into the SCC or SDC. Transfer the contents of the 4K memory, origin C000, to the 4K memory, origin A000, via the MOVE utility program. Enter 8080 into memory location 8080 and 8081. Depress the RESET button. Enter 1008 into memory location 8000. Store to memory location FFD1 and FFDB in sequence with the LCP to start the Slave 1 Processor. After 5 seconds, examine memory locations 8080 and 8081 and verify that they contain the following information:

Witnessed by:

Customer Representative \_\_\_\_\_

Raytheon QA Representative \_\_\_\_\_

Date \_\_\_\_\_

### 2.5.3 Slave Bus 2 Test (continued)

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
8080	0000	Halt Code
8081	0000	Success Code

### 2.6 System Test

Initial

- (a) Requirements -
  - (i) Verify control of the Slave processors by the Master processor, including Control Interface, high level interrupts from Master to Slaves, and low level interrupts from Slaves to Masters.
  - (ii) Verify generation of synchronized Real Time Clock of Master and Slave 1 processors, including Master control of Slave RTC and Internal Interrupt Generation for Slave 1 processor.
  - (iii) Verify communication of Slave 1 and Slave 2 processors through the common two port memories.
  - (iv) Test the Aux. Bus connector port in conjunction with SS connector port stimulation.
  - (v) Verify the auto-start feature.
- (b) Condition - Basic test configuration (with SCM bootstrap test PROMs).
- (c) Measurement - Load the SC system test program into the SSC or SDC. Load the tape containing the SS operational software on the device assigned to BIN2. Start the SSC at location 8100. Using the LCP store 0080 into locations 0080 and 0081. Depress the RESET button. Start the SC at location C102. When the RUN light goes out, examine memory locations 0080 and 0081 for the following data:

<u>Memory Location</u>	<u>Contents</u>	<u>Meaning</u>
0080	0000	Halt Code
0081	0000	Success Code

Witnessed by:

Customer Representative:

Raytheon QA Representative:


- Turn power off for (5) seconds, then turn power on and, when the RUN light goes out after about (15) seconds, confirm that the Master Processor P register contains FF04.

D&D

**APPENDIX A**

**BASIC TEST EQUIPMENT CONFIGURATION**

System Controller Test Configuration



APPENDIX B  
TEST PROGRAMS

5413:IEWS:76:69    RP-16 CP Test - PROM Version  
5413:IEWS:76:70    Memory Test - PROM Version  
5413:IEWS:76:71    IEWS SC Test  
                    PIN/RTC Test  
                    SIØ Test  
                    SCM Test  
                    Master Bus Test  
                    SP1 Bus Test  
                    SP2 Bus Test  
5413:IEWS:76:72    IEWS SC System Test

## APPENDIX C

### OPERATING PROCEDURE FOR MOVE ROUTINE

1. Enter the origin of the 4K memory module, which the program is to be moved FROM, into the XR Register.
2. Enter the origin of the 4K memory module, which the program is to be moved TO, into the BR Register.
3. Enter 05EO into the PR Register, and depress the RESET button.
4. Put the RP-16 into RUN mode.

## APPENDIX D

### OPERATING PROCEDURE FOR THE SSC

1. Load the operating system into the SSC and start it.
2. Mount the tape containing the program to be loaded onto Magnetic Tape Drive 0.
3. Type the following commands on the INFOTON keyboard:

```
AS  BIN1, MT0  
AS  BIN2, MTL  
RW  BIN1  
BI  8000  
LO
```

To start a program in the SSC, type the command:

```
GO  address
```